

# PartsGo Industrial Parts RFQ Guide

## Any Bus

PartsGo is an independent RFQ and sourcing platform unless a specific relationship is explicitly stated. This guide does not claim public stock, price, same-day shipment, or official distributor status.

## RFQ checklist

- Exact brand name and part number
- Required quantity and target delivery country
- New, surplus, replacement, or repair preference if known
- Machine, line, or project context when it helps identify the part
- Urgency, deadline, and any acceptable alternatives

## Common references

Any Bus 017505  
Any Bus 018410  
Any Bus 019350  
Any Bus 021450-B  
Any Bus 023040-B  
Any Bus 023140-B  
Any Bus 024140-B  
Any Bus 024380-B  
Any Bus 025070-B  
Any Bus 24380  
Any Bus 2986329-81  
Any Bus A016aaeb  
Any Bus Ab405 Customized  
Any Bus Ab4582-B  
Any Bus Ab6221-C  
Any Bus Ab7000-C  
Any Bus Ab7000-C Serial:000230a4  
Any Bus Ab7001  
Any Bus Ab7007-C  
Any Bus Ab7007hms  
Any Bus Ab700c-Hms  
Any Bus Ab7013  
Any Bus AB7013-C  
Any Bus Ab7015-C  
Any Bus Ab7029-C Serial: 0001274e Cb V.2.2.1 Not Available,Replaced By Ab7000-C  
Any Bus Ab7048  
Any Bus Ab7049  
Any Bus Ab7303  
Any Bus Ab7309  
Any Bus Ab7312-B  
Any Bus Ab7314-B  
Any Bus AB7317  
Any Bus Ab7318  
Any Bus Ab7504-F  
Any Bus AB7558-F  
Any Bus Ab7607  
Any Bus Ab7612-B

Any Bus Ab7620  
Any Bus Ab7623  
Any Bus Ab7624

## How to request a quote

Visit <https://partsgo.net/request-quote> and send brand, part number, quantity, delivery country, company, contact details, and urgency.