

PartsGo Industrial Parts RFQ Guide

Beta

PartsGo is an independent RFQ and sourcing platform unless a specific relationship is explicitly stated. This guide does not claim public stock, price, same-day shipment, or official distributor status.

RFQ checklist

- Exact brand name and part number
- Required quantity and target delivery country
- New, surplus, replacement, or repair preference if known
- Machine, line, or project context when it helps identify the part
- Urgency, deadline, and any acceptable alternatives

Common references

Beta 00001950019
Beta 00004300002
Beta 00004300003
Beta 00004300004
Beta 00004300005
Beta 00004300007
Beta 00004300008
Beta 00004300010
Beta 00004300011
Beta 00004300016
Beta 00004460060
Beta 00005600020
Beta 00009280862
Beta 00015000325
Beta 00019310013
Beta 00019360024
Beta 00019460001
Beta 000420008
Beta 000420010
Beta 000420013
Beta 000780036
Beta 000780050
Beta 000960354
Beta 000960380
Beta 000960685
Beta 000961354
Beta 001420069
Beta 003360001
Beta 003360001 336
Beta 003830002
Beta 003830002 383/2 220mm
Beta 005900003
Beta 006060105
Beta 006060110
Beta 006800035
Beta 007280322
Beta 007280424

Beta 009000203
Beta 009000814
Beta 009200425

How to request a quote

Visit <https://partsgo.net/request-quote> and send brand, part number, quantity, delivery country, company, contact details, and urgency.