

# PartsGo Industrial Parts RFQ Guide

## Dormer

PartsGo is an independent RFQ and sourcing platform unless a specific relationship is explicitly stated. This guide does not claim public stock, price, same-day shipment, or official distributor status.

### RFQ checklist

- Exact brand name and part number
- Required quantity and target delivery country
- New, surplus, replacement, or repair preference if known
- Machine, line, or project context when it helps identify the part
- Urgency, deadline, and any acceptable alternatives

### Common references

Dormer 135035 M6 Gew-Bohrer Hsse-V3 Inox Din 371/B M 6 X1,00 Precitool  
Dormer ?195?8 Din 371  
Dormer ?245?12 Din 376  
Dormer ?245?16 Din 376  
Dormer ?245?20 Din 376  
Dormer 25 X 25 X 154 X 30 Right Hand 306 (Type Al/R25-16)  
Dormer 29 X 250 X 60 X 32 X 25 X 16.3 X 29 Right Hand 410 (Type Avr/L 25-16)  
Dormer 792-260  
Dormer 8.9mm X 115mm Flute X 175mm Oal Alcrn Coating Pfx Cobalt Taper Length Drill  
Dormer A12220.0  
Dormer A122 20.00mm (120 Deg)  
Dormer A12220.0x120  
Dormer A9403.5  
Dormer C49210.0  
Dormer C49214.0  
Dormer C49216.0  
Dormer C49218.0  
Dormer C49220.0  
Dormer C92210.0  
Dormer C92211.0  
Dormer C92214.0  
Dormer C92218.0  
Dormer C92220.0  
Dormer Dormer-A00210.0  
Dormer Dormer-A0023.0  
Dormer Dormer-A0023.3  
Dormer Dormer-A0023.5  
Dormer Dormer-A0024.0  
Dormer Dormer-A0024.2  
Dormer Dormer-A0024.5  
Dormer Dormer-A0025.0  
Dormer Dormer-A0025.5  
Dormer Dormer-A0026.0  
Dormer Dormer-A0026.5  
Dormer Dormer-A0026.8  
Dormer Dormer-A0027.0  
Dormer Dormer-A0027.5

Dormer Dormer-A0028.0  
Dormer Dormer-A0028.5  
Dormer Dormer-A0029.0

## How to request a quote

Visit <https://partsgo.net/request-quote> and send brand, part number, quantity, delivery country, company, contact details, and urgency.