

# PartsGo Industrial Parts RFQ Guide

## Foss

PartsGo is an independent RFQ and sourcing platform unless a specific relationship is explicitly stated. This guide does not claim public stock, price, same-day shipment, or official distributor status.

### RFQ checklist

- Exact brand name and part number
- Required quantity and target delivery country
- New, surplus, replacement, or repair preference if known
- Machine, line, or project context when it helps identify the part
- Urgency, deadline, and any acceptable alternatives

### Common references

Foss 10004893  
Foss 10007586  
Foss 15840087  
Foss 50002262  
Foss 500108  
Foss 60026918  
Foss 60028288  
Foss 60031810  
Foss 60078398  
Foss 844787  
Foss 91890467  
Foss Autosystem 8400  
Foss Ds 2500  
Foss Fibertec? M6  
Foss Foss  
Foss Kjeltec 2200 Obsolete, Replaced By Kjeltec 8100/60063211 And Kjeltec 8200 / 60063212  
Foss Kjeltec 2300 - Obsolete, Replaced By Kjeltec 8400  
Foss Kjeltec 8100 / 60063211  
Foss Kjeltec 8200 / 60063212  
Foss Kjeltec 8400  
Foss Kn 195  
Foss Kn 195 Knifetec  
Foss Pcb1052104-1  
Foss Soxtec 2055  
Foss Soxtec 8000  
Foss Winescan Tm So2

### How to request a quote

Visit <https://partsgo.net/request-quote> and send brand, part number, quantity, delivery country, company, contact details, and urgency.