

# PartsGo Industrial Parts RFQ Guide

## Huller

PartsGo is an independent RFQ and sourcing platform unless a specific relationship is explicitly stated. This guide does not claim public stock, price, same-day shipment, or official distributor status.

### RFQ checklist

- Exact brand name and part number
- Required quantity and target delivery country
- New, surplus, replacement, or repair preference if known
- Machine, line, or project context when it helps identify the part
- Urgency, deadline, and any acceptable alternatives

### Common references

Huller A.1001.6389 (Ex 10170.22060)  
Huller A.1002.4042 (Ex 10303.5084)  
Huller A.1002.6906 (Ex 1050303088)  
Huller A.1002.6907 (Ex 10503.03096)  
Huller A.1003.9976 (Ex 11008.13706)  
Huller A.1004.0035 (Ex 11008.48868)  
Huller A.1004.0059 (Ex 11008.49635)  
Huller A.1004.0169 (Ex 11008.51607)  
Huller A.1004.0171 (Ex 1100851623)  
Huller A.1004.0268 (Ex 11008.54445)  
Huller A.1004.0686  
Huller A.1004.0687 (Ex 1100875176)  
Huller A.1004.0688 (Ex 11008.75184)  
Huller A.1004.0971 (Ex 1100886264)  
Huller A.1004.0981 (Ex 1100886363)  
Huller A.1004.1067 (Ex 11008.88468)  
Huller A.1004.1238 (Ex11008.97451)  
Huller A.1005.1850 (Ex 16005.48646-2)  
Huller A.1005.1851 (Ex 16005.48653-2)  
Huller A.1067.0091  
Huller A.1089.4658  
Huller A.1090.7992  
Huller Ad.0051.5804 (Ex 11206.82545)  
Huller Ad.1004.0268 (Ex 1100854445)

### How to request a quote

Visit <https://partsgo.net/request-quote> and send brand, part number, quantity, delivery country, company, contact details, and urgency.