

PartsGo Industrial Parts RFQ Guide

Küenle

PartsGo is an independent RFQ and sourcing platform unless a specific relationship is explicitly stated. This guide does not claim public stock, price, same-day shipment, or official distributor status.

RFQ checklist

- Exact brand name and part number
- Required quantity and target delivery country
- New, surplus, replacement, or repair preference if known
- Machine, line, or project context when it helps identify the part
- Urgency, deadline, and any acceptable alternatives

Common references

Küenle 0217
Küenle 068.03-3112.0
Küenle 068.03-3113.0
Küenle 1.
Küenle 1085
Küenle 1110452981
Küenle 1113
Küenle 1114
Küenle 11810
Küenle 1314
Küenle 132S-UL/CSA
Küenle 1506
Küenle 151-0002
Küenle 15731
Küenle 16770
Küenle 1912
Küenle 21052
Küenle 2311
Küenle 23530
Küenle 2397
Küenle 2407
Küenle 2609
Küenle 27540
Küenle 28905
Küenle 2906
Küenle 297301105
Küenle 2991212853
Küenle 300288
Küenle 300376
Küenle 300378
Küenle 300458
Küenle 300820
Küenle 300895
Küenle 301947
Küenle 302757
Küenle 303406
Küenle 3205-4124161

Küenle 3311
Küenle 34068
Küenle 34071

How to request a quote

Visit <https://partsgo.net/request-quote> and send brand, part number, quantity, delivery country, company, contact details, and urgency.