

# PartsGo Industrial Parts RFQ Guide

## Mte

PartsGo is an independent RFQ and sourcing platform unless a specific relationship is explicitly stated. This guide does not claim public stock, price, same-day shipment, or official distributor status.

### RFQ checklist

- Exact brand name and part number
- Required quantity and target delivery country
- New, surplus, replacement, or repair preference if known
- Machine, line, or project context when it helps identify the part
- Urgency, deadline, and any acceptable alternatives

### Common references

Mte 01-0000-01-000  
Mte 01-0000-02-005  
Mte 01-0000-03-002  
Mte 01-000016-007  
Mte 01-0000-51-020  
Mte 01-0000-51-023  
Mte 01-0000-51-024  
Mte 01-0000-51-030  
Mte 01-0001-30-002  
Mte 01-000130-003  
Mte 01000130-004  
Mte 01-000130-008  
Mte 01-000130-012  
Mte 01-0001-53-002  
Mte 01-0001-53-008  
Mte 01-0001-53-023  
Mte 01-0001-53-028  
Mte 01-0001-53-030  
Mte 01-000158-221  
Mte 01-0001-59-006  
Mte 01-000800-000  
Mte 01-0008-06-012  
Mte 01-0008-07-014  
Mte 01-0008-08-003  
Mte 01-0008-51-034  
Mte 01-0008-64-014  
Mte 01-0008-67-019  
Mte 01-001100.016  
Mte 01-001-54-004  
Mte 01-008-20-14  
Mte 01-008-21-014  
Mte 01-008-22-010  
Mte 01-008-22-013  
Mte 01-008-23-014  
Mte 01-030150-115  
Mte 01-0303-50-240  
Mte 01-0407-00-000

Mte 01-0410-00-024  
Mte 01-0420-50-240  
Mte 01-0430-00-000

## How to request a quote

Visit <https://partsgo.net/request-quote> and send brand, part number, quantity, delivery country, company, contact details, and urgency.