

# PartsGo Industrial Parts RFQ Guide

## Schnorr

PartsGo is an independent RFQ and sourcing platform unless a specific relationship is explicitly stated. This guide does not claim public stock, price, same-day shipment, or official distributor status.

### RFQ checklist

- Exact brand name and part number
- Required quantity and target delivery country
- New, surplus, replacement, or repair preference if known
- Machine, line, or project context when it helps identify the part
- Urgency, deadline, and any acceptable alternatives

### Common references

Schnorr 001 300  
Schnorr 002500  
Schnorr 002500 Tf B 12 5 6 2 0 5  
Schnorr 002500 ? Tf B 12,5 X 6,2 X 0,5 Phosphatiert+geolt  
Schnorr 002621  
Schnorr 002700, A12,5, Din 2093  
Schnorr 002750, C14 Din2093  
Schnorr 002900  
Schnorr 003467 / PLATE SPRING  
Schnorr 003468 / PLATE SPRING  
Schnorr 004300, B16, Din2093  
Schnorr 005 100  
Schnorr 005 550  
Schnorr 005600  
Schnorr 005600 (pack 500 pcs)  
Schnorr 005600 / TELLERFEDER DIN 2093  
Schnorr 007200  
Schnorr 007600  
Schnorr 008350  
Schnorr 008800, B25 Din 2093  
Schnorr 009100  
Schnorr 009100, A25, Din2093  
Schnorr 010100  
Schnorr 010200  
Schnorr 010700, B31,5g, Din2093  
Schnorr 0109009  
Schnorr 011100  
Schnorr 011700  
Schnorr 012  
Schnorr 012000  
Schnorr 012700  
Schnorr 012700 C  
Schnorr 013  
Schnorr 013100  
Schnorr 013300  
Schnorr 013 433  
Schnorr 014 500

Schnorr 014600, B50g, Din 2093

Schnorr 014800

Schnorr 015000

## How to request a quote

Visit <https://partsgo.net/request-quote> and send brand, part number, quantity, delivery country, company, contact details, and urgency.