

PartsGo Industrial Parts RFQ Guide

Schroff

PartsGo is an independent RFQ and sourcing platform unless a specific relationship is explicitly stated. This guide does not claim public stock, price, same-day shipment, or official distributor status.

RFQ checklist

- Exact brand name and part number
- Required quantity and target delivery country
- New, surplus, replacement, or repair preference if known
- Machine, line, or project context when it helps identify the part
- Urgency, deadline, and any acceptable alternatives

Common references

Schroff 001
Schroff 001 13100-043+001 21006-943
Schroff 001 13100-043 /Netzgerö;T Ohne Frontplatte
Schroff 001 20818-022
Schroff 001 20860-108
Schroff 001 20860-228
Schroff 001 21101-218
Schroff 001 21101-219
Schroff 001 21101-568
Schroff 001 23006-814
Schroff 001 23007-421
Schroff 001 23098-105
Schroff 001 30809-428
Schroff 001 30838-081
Schroff 001 30838-162
Schroff 001 60809-032
Schroff 001 60817-149
Schroff 01
Schroff 01 21006-943 / Frontplatte
Schroff 10130-198
Schroff 10225-324
Schroff 10225-615
Schroff 10225-618
Schroff 10225-624
Schroff 10225627
Schroff 10225-637
Schroff 10225-670
Schroff 10225-682
Schroff 10225-685
Schroff 10225-693
Schroff 10225-696
Schroff 10234381
Schroff 10501-006
Schroff 10501-025
Schroff 10501-028
Schroff 10501-116
Schroff 10502-276

Schroff 10502-277
Schroff 10502-281
Schroff 10502-288

How to request a quote

Visit <https://partsgo.net/request-quote> and send brand, part number, quantity, delivery country, company, contact details, and urgency.