

# PartsGo Industrial Parts RFQ Guide

## Testo

PartsGo is an independent RFQ and sourcing platform unless a specific relationship is explicitly stated. This guide does not claim public stock, price, same-day shipment, or official distributor status.

### RFQ checklist

- Exact brand name and part number
- Required quantity and target delivery country
- New, surplus, replacement, or repair preference if known
- Machine, line, or project context when it helps identify the part
- Urgency, deadline, and any acceptable alternatives

### Common references

Testo 0133  
Testo 0133 0010  
Testo 0390  
Testo 03900070  
Testo 0390 0072  
Testo 0390 0074  
Testo 0390-0075  
Testo 0390 0078  
Testo 0390-0081  
Testo 0390 0088  
Testo 0393  
Testo 0393 0000 O2-Sensor  
Testo 0393 0100  
Testo 0393 0150  
Testo 03930200  
Testo 0393 0300  
Testo 0409  
Testo 0409 0063  
Testo 0430  
Testo 0430 0065  
Testo 0430 0071  
Testo 0430 0143  
Testo 0449  
Testo 0449 0075  
Testo 0449 0076  
Testo 0449 0077  
Testo 05150  
Testo 05150 0100  
Testo 0516  
Testo 0516 0201  
Testo 0516 0221  
Testo 0516-3400  
Testo 0516 3510  
Testo 0516 7900  
Testo 0520  
Testo 0520 0003  
Testo 0520 0034

Testo 0554  
Testo 0554 0168  
Testo 0554 0289

## How to request a quote

Visit <https://partsgo.net/request-quote> and send brand, part number, quantity, delivery country, company, contact details, and urgency.