

PartsGo Industrial Parts RFQ Guide

Vdo

PartsGo is an independent RFQ and sourcing platform unless a specific relationship is explicitly stated. This guide does not claim public stock, price, same-day shipment, or official distributor status.

RFQ checklist

- Exact brand name and part number
- Required quantity and target delivery country
- New, surplus, replacement, or repair preference if known
- Machine, line, or project context when it helps identify the part
- Urgency, deadline, and any acceptable alternatives

Common references

Vdo 02070009 Tachometer

Vdo 02 240 401

Vdo 02 240 403 Oem

Vdo 10001 Kienzlemhsensetech

Vdo 10002 Kienzlemhsensetech

Vdo 10003 Kienzlemhsensetech

Vdo 10004 Kienzlemhsensetech

Vdo 10006 Kienzlemhsensetech

Vdo 10007 Kienzlemhsensetech

Vdo 10008 Kienzlemhsensetech

Vdo 10009 Kienzlemhsensetech

Vdo 10010 Kienzlemhsensetech

Vdo 10011 Kienzlemhsensetech

Vdo 10012 Kienzlemhsensetech

Vdo 10021 Kienzlemhsensetech

Vdo 10022 Kienzlemhsensetech

Vdo 10023 Kienzlemhsensetech

Vdo 10024 Kienzlemhsensetech

Vdo 10025 Kienzlemhsensetech

Vdo 10026 Kienzlemhsensetech

Vdo 10027 Kienzlemhsensetech

Vdo 10031 Kienzlemhsensetech

Vdo 10051 Kienzlemhsensetech

Vdo 10101 Kienzlemhsensetech

Vdo 10102 Kienzlemhsensetech

Vdo 10103 Kienzlemhsensetech

Vdo 10104 Kienzlemhsensetech

Vdo 10105 Kienzlemhsensetech

Vdo 10106 Kienzlemhsensetech

Vdo 10107 Kienzlemhsensetech

Vdo 10108 Kienzlemhsensetech

Vdo 10109 Kienzlemhsensetech

Vdo 10110 Kienzlemhsensetech

Vdo 10111 Kienzlemhsensetech

Vdo 10112 Kienzlemhsensetech

Vdo 10113 Kienzlemhsensetech

Vdo 10114 Kienzlemhsensetech

Vdo 10115 Kienzlemhsensetech
Vdo 10116 Kienzlemhsensetech
Vdo 10117 Kienzlemhsensetech

How to request a quote

Visit <https://partsgo.net/request-quote> and send brand, part number, quantity, delivery country, company, contact details, and urgency.