

PartsGo Industrial Parts RFQ Guide

Bd Sensors

PartsGo is an independent RFQ and sourcing platform unless a specific relationship is explicitly stated. This guide does not claim public stock, price, same-day shipment, or official distributor status.

RFQ checklist

- Exact brand name and part number
- Required quantity and target delivery country
- New, surplus, replacement, or repair preference if known
- Machine, line, or project context when it helps identify the part
- Urgency, deadline, and any acceptable alternatives

Common references

Bd Sensors 0-10 Bar, 4-20 mA, 2
Bd Sensors 026872644
Bd Sensors 100-S050-E-5-M10-300-1-000
Bd Sensors 100-S250-E-5-M10-300-1-000
Bd Sensors 105013
Bd Sensors 110-1000-1-5-100-200-3-000
Bd Sensors 110 1002 1 2 100 800 1 000
Bd Sensors 110 1002 3 3 M00 300 1 000
Bd Sensors 110-1500-1-5-100-F00-1-000
Bd Sensors 110-1602-1S-3-100-200-1-000
Bd Sensors 110-2500-E-5-100-F00-1-000
Bd Sensors 110 2502 1 2 100 800 1 000
Bd Sensors 110-2502-E-3-100-F00-1-000
Bd Sensors 110-4000-1-5-100-100-1-000
Bd Sensors 110-M400-3-3-M00-F00-1-000
Bd Sensors 110-M400-3-5-M00-F00 - 1-000
Bd Sensors 110-S050-1-5-100-200-1-000
Bd Sensors 111-1002-3-3-M00-300-1-000
Bd Sensors 116844
Bd Sensors 130-1003-1-2-100-800-5-000
Bd Sensors 130 1603 1 2 100 800 5 000
Bd Sensors 130-1603-1-5-10-3-5-000 Transmitter
Bd Sensors 130-2503-1-2-100-800-5-000
Bd Sensors 130-2503-3-3-100-100-5-000
Bd Sensors 130-4502-2-3-M00-D15-5-520
Bd Sensors 130 6003 1 2 100 800 5 000
Bd Sensors 18.601
Bd Sensors 18.601 G-1601-R-1-5-100-300-3-000
Bd Sensors 18.605-1001-M-1-5-1-006-300-1-000
Bd Sensors 18.605-1001-M-1-5-1-012-300-1-000
Bd Sensors 18.605G-1001-M-1-5-1-006-300-1-000
Bd Sensors 18.605g-4000-M-1-5-1-006-300-1-000
Bd Sensors 18.605G, inkl. 20m PVC-Kabel
Bd Sensors 210-1503-1-5-100-N40-2-008
Bd Sensors 250-2503-1-5-Tr0-400-1-1-2-000 Dmk 331
Bd Sensors 250-4003-3-5-100-700-5-1-2-000
Bd Sensors 26.600G

Bd Sensors 26.600g-1001-R-1-5-100-300-1-000
Bd Sensors 26.600g-1002-R-1-5-100-200-1-000
Bd Sensors 26.600 G-1002-R-1-5-100-300-1-000

How to request a quote

Visit <https://partsgo.net/request-quote> and send brand, part number, quantity, delivery country, company, contact details, and urgency.